



US30 Series Accessories Guide



Cradle

2-Slot Cradle (2 type)
5-Slot Cradle (4 type)



Functionality

30 key / 38key/ 42 key / 51 key
Long Range Scanner
45 Angle Scanner



Trigger Handle
Vehicle Cradle
Boot



Battery Charger

4-Slot / 20-Slot Battery Charger



MISCELLANEOUS

USB Cable
Hand strap
Stylus
Holster
Screen Protector

* More accessories will be added.



2-Slot Charging Cradle



2-Slot Ethernet Cradle

US20-2CRD-CU0

2-Slot Charging Cradle

US20 2-Slot charging & USB host client cradle for 1xUS20 & 1xUS20 spare battery.

Requires power supply (US20-PWSP-2XX; sold separately)

US20-2CRD-ECO

2-Slot Ethernet Cradle

US20 2-Slot charging & Ethernet USB client cradle for 1xUS20 & 1xUS20 spare battery.

Requires power supply (US20-PWSP-2XX; sold separately)



Power Supply

US20-PWSP-2AU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes AU power cord.

US20-PWSP-2CN

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes CN power cord.

US20-PWSP-2EU

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes EU power cord.

US20-PWSP-2KR

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes KR power cord.

US20-PWSP-2UK

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes UK power cord.

US20-PWSP-2US

Power Supply: 100~240VAC, 12VDC, 3A. Provides power to the 2-Slot cradle with US20. Includes US power cord.



5-Slot Charging Cradle



5-Slot Ethernet Cradle

5-Slot Charging Cradle for
4 x US20 & 4 Batteries5-Slot Ethernet Cradle
for 4 x US20 & 4 Batteries

Power Supply

US20-5CRD-C00

5-Slot Charging Cradle

US20 5-Slot charging only cradle for 5 x US20. Requires power supply (US20-PWSP-5XX; sold separately)

US20-5CRD-E00

5-Slot Ethernet Cradle

US20 5-Slot charging & Ethernet cradle for 5 x US20. Requires power supply (US20-PWSP-5XX; sold separately)

US20-5CRD-C00-MT

5-Slot Charging Cradle for 4 x US20 & 4 Batteries

US20 5-Slot charging only cradle for 4 x US20 & 4 Batteries. Requires power supply (US20-PWSP-5XX; sold separately)

US20-5CRD-E00-MT

5-Slot Ethernet Cradle for 4 x US20 & 4 Batteries

US20 5-Slot charging & Ethernet cradle for 4 x US20 & 4 Batteries. Requires power supply (US20-PWSP-5XX; sold separately)

US20-PWSP-5AU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes AU power cord.

US20-PWSP-5CN

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes CN power cord.

US20-PWSP-5EU

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes EU power cord.

US20-PWSP-5KR

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes KR power cord.

US20-PWSP-5UK

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes UK power cord.

US20-PWSP-5US

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US power cord.



US20-TRIG-S00

Scanning Trigger Handle for US20

- Reduce wrist fatigue when workers are using terminals for long time.
- Save time by counting stocks in warehouse.
- The design is ergonomically made by measurement in mechanical team.
- The trigger handle has essential functions properly in industrial environments.
- The US20 and Tigger handle can be removed quickly and easily, depending on the situation.



US20-VCRD-CU0

US20 Forklift/Vehicle Charging & USB Host Client Cradle by M3 mounted USB cable. Requires forklift / vehicle mount(UNIV-RAMX; sold separately)

**Order Separately: Mount, Voltage Power Converter, cable, Auto Adapter and USB(host, client) cable



UNIV-CABL-UVH

USB Host Cable for Forklift/Vehicle Cradle

UNIV-CABL-UVC

USB Client Cable for US20 Forklift/Vehicle Cradle



UNIV-RAMM

RAM® Double Socket Arm mount for Forklift Cradle

UNIV-RAMC

Clamp base for Forklift Cradle. Attach to the forklift Socket Arm mount.

UNIV-RAMU

U-bolt base for Forklift Cradle. Attach to the forklift Socket Arm mount.

UNIV-CABL-VC

Forklift power extend input cable, Length : 1M

UNIV-PWSP-F00

Forklift Voltage Power Converter, INPUT : DC 24V ~ DC 96.V, OUTPUT : DC 12V / 5A



UNIV-RAMT

Vehicle Mount for Vehicle Cradle by RAM®. Install in a vehicle by tighten screw.

UNIV-RAMS

Vehicle Mount for Vehicle Cradle by RAM®. Install in a vehicle by suction.

UNIV-PWSP-VVC

Auto Charger Cable: Input 12-24VDC / Output 5VDC, 2A (Cigarette Lighter Adapter)
Provides power to vehicle cradle (US20-VCRD-CU0)



US20-BOOT-01

Use a case to protect the PDA from shocks

Battery Charger



4-Slot Battery Charger



20-Slot Battery Charger

US20-04BC-C00

4-Slot Battery Charger

M3 Battery charging station for US20, 4-Slot Battery Charging Station. Requires power supply (US20-PWSP-2XX; sold separately)

US20-20BC-C00

20-Slot Battery Charger

5-Slot charging cradle for 20 Batteries (5 x 4 Slot Battery Charging Station). Requires power supply (US20-PWSP-5XX; sold separately)



Battery

US20-BATT-E67(US20-BATT-E67-S10): US20 Fast Charging Extended Capacity Spare Battery 6,700mAh (10 pcs)



Power Supply



Power Supply

**US20-PWSP-2US / US20-PWSP-2UK / US20-PWSP-2KR /
US20-PWSP-2EU / US20-PWSP-2CN / US20-PWSP-2AU**

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US / UK / KR / EU / CN / AU power cord.

**US20-PWSP-5US / US20-PWSP-5UK / US20-PWSP-5KR /
US20-PWSP-5EU / US20-PWSP-5CN / US20-PWSP-5AU**

Power Supply: 100~240VAC, 12VDC, 12.5A. Provides power to the 5-Slot cradle with US20. Includes US / UK / KR / EU / CN / AU power cord.

MISCELLANEOUS



USB Cable

US20-CABL-UCA

USB cable, 1.2M, C to A plug for US20
Requires power supply (US20-PWSP-U00; sold separately)



Hand Strap

US20-STRP-(S10 or S50)

Hand strap for 45° Scan US20 (10 pcs or 50 pcs)

US20-STRP-(E10 or E50)

Hand strap for 0° Scan US20 (10 pcs or 50 pcs)

US20-STRP-(T10 or T50)

Hand strap for Trigger Handle US20 (10 pcs or 50 pcs)



Stylus pen

US20-STYL

Spare Stylus with tether for US20



Soft type Holster

US20-CASE-FSH

Soft type Fabric Holster with Strap, belt



Screen protector

US20-SCPR

Bullet proof Screen Protector for US20



Hard type Holster

US20-CASE-FHH

Hard type Fabric Holster with Strap, belt

Choice of US20 Functionality for Convenient Use

The following are not accessories, but SKUs are different for each keypad.



● **Numeric 30-Key**



● **Alpha Numeric 51-Key**




● **Functional 38-Key**



● **Functional 42-Key**

The following are not accessories, but SKUs are different for each scanner.



● **Long Range Scanner**

Long Range Scanner
Able to read maximum 21.4 meters

*The SKU of the scanner is divided into 2D and LR.

Angled Scanner (45 degrees)
Helps comfortable aiming
Reduces wrist fatigue with ergonomic design.

*This SKU could not use Trigger Handle (US20-TRIG-S00).



● **Angled Scanner**

USE IT THIS WAY

It's the most complete and useful way to use it.

Parcel delivery

US20 + Vehicle Cradle

Warehouse

US20 + Trigger Handle + Forklift Cradle

Inventory Management

US20 + Various Keypad

Load and unloading

US20 + Battery Charger

Warehouse Management

US20 + Forklift Cradle